

# NOVA



Insert a blunt tip needle (14ga or smaller) into the space between the center airway tube and the inner wall of the disposable. We recommend an oil temperature range of 90°F-130°F when filling.

**Caution:**

- Do not allow oil to enter the center airway tube.
- Do not overfill. If you overfill a disposable fluid will be forced through the atomizer and leak out of the bottom of the disposable when the mouthpiece is capped.



Capping the mouthpiece by hand punch immediately after filling.

**Caution:**

- The disposable must be upright and centered with the mouthpiece when pressing down.
- Failure to capping immediately after filling may cause leakage.



Allow your disposable to stand for at least 30 minutes.

During this time, oil is priming the atomizer. The rate that the atomizer saturates is dependent upon the viscosity of the oil. More viscous oils will require more time.